

Grinder

[Coffee Mill smart G_MSG-2-T/TB]

Q. How do I take it apart?

A. Follow the disassembly instructions below.

(1) Rotate the ground coffee bottle clockwise (right) to remove it from the hopper.




(2) Rotate the grind adjustment knob counterclockwise (left) to take it off. Remove the inner burr from the shaft, then remove the locking pin set inside the inner burr.



*If the grind adjustment knob is too tight, make it easier to turn by doing so while holding the handle to keep the shaft in place.



(3) Remove the handle from the shaft and take the lid off of the top of the hopper.



(4) Remove the spring and the hopper shaft cover from bottom of the hopper. Finally, remove the shaft and washer to finish disassembly.



(5) Disassembly is complete.



In order from the right hand side,

- 1 Hopper
- 2 Washer
- 3 Shaft
- 4 Hopper Shaft Cover
- 5 Spring
- 6 Inner Burr
- 7 Setting Pin
- 8 Grind Adjustment Knob
- 9 Lid
- 10 Handle
- 11 Bottle