

HARIO



Matcha Collection

Matcha Latte Frother

家庭用・保証書付き

取扱説明書



電子レンジ用

⚠ 注意

●直火にかけられません

お買いあげ誠にありがとうございます。正しくご使用していただくため、この取扱説明書を必ずお読みください。また、お読みになりましたら、大切に保管してください。

For Microwave Use


⚠ CAUTION!

Instruction Manual

Do not expose to open flames.

Thank you for purchasing this HARIO product. Please be sure to read this instruction manual thoroughly prior to use. After reading the manual, store it in a safe place for future reference.

材質のご案内 Material Guide



HARIO Glass®
は HARIO の耐熱ガラス素材の商標です。

この製品は日本で品質管理し、組立てたものです。


This product is assembled to strict quality control standards in Japan.

How to Make Matcha Latte

Ingredients

Matcha powder.....	1-2 tea spoons (approx.5g)
Milk.....	Approx. 200mL
Ice.....	To taste

※To sweeten, add syrup or honey to taste.



1. Pour milk into the glass body until the top of logo. (or until the 100mL scale mark).



2. Sift in 1–2 teaspoons (approx. 5g) of matcha powder with a strainer.



3. Attach the lid and handle set, and run the motor for about 30 seconds.

※ Add syrup or honey to taste.



4. Fill the glass with ice, then pour milk up to the top mark.




5. Mix lightly and enjoy as is.

Additional Recipe

Fluffy Matcha Drink (hot, 2 servings)

●● Make the milk froth. ●●



1. Pour in 100mL of milk into the glass body until the top of logo (or scale until 100mL).

※ A fat content of 3.5% or more is ideal.



2. Heat in a 600W microwave for about 30 seconds.

※ Be sure to remove the lid and handle set before heating only the glass body in the microwave.

※ The ideal heating temperature is 40°C to 50°C. Heating times may vary depending on your microwave; checking with a thermometer is recommended.



3. Place the lid and handle then whisk for about 20-40 seconds.

※ Foam is easier to create by tilting the glass and moving the handle set up and down.

A layer of foam gradually rises



4. Pour the frothed milk into a cup.



5. Put 200mL of hot water and about 5g of sifted matcha powder into the glass body, and run the motor to whisk.

※ Add syrup or honey to taste.



6. Pour the matcha over the frothed milk in the cup.

※ Top with matcha powder if you like.

※ For iced drinks, pour the frothed milk and matcha into a glass filled with ice.



About the Glass Body

Precautions for Use

- ⚠ Take out the lid and handle set before microwave use. Only the glass body should be heated in the microwave.
- ⚠ Do not use with any heating device other than a microwave oven.
- ⚠ Glass is fragile and may break. Handle carefully during normal use and cleaning.
- ⚠ Do not allow children to use this product. Do not use near children, and store out of reach of children.

- Wash the product before using for the first time.
- To prevent injury, make sure there are no cracks or chips prior to use.
- Do not use the product if it is cracked, broken, or heavily scratched as it may break unexpectedly.
- Do not strike or scrape the inside of the glass container with a metal spoon. Doing so may damage the product.
- Do not touch the glass container with a wet cloth or place on a wet surface while hot, as doing so may damage the glass related to sudden temperature change.
- Mixing or stirring hard ingredients such as ice may scratch the glass and cause damage.
- If the product becomes damaged, please handle any broken pieces with care.
- Follow local rules on garbage disposal when disposing of this product.

Precautions for Use in a Microwave

- ⚠ Liquid may boil rapidly, causing the liquid to suddenly be expelled from the container (known as the bumping phenomenon). Keep your face away from the product when removing from a microwave.
- ⚠ Do not use in microwave ovens with an interior height of less than 15 cm.
- ⚠ We recommend using a microwave with a heating wattage of 600 W or less. Heat using the time-setting mode only; do not use the temperature-setting mode or weight-sensor mode. If the amount of milk being heated is small, it may overheat, or in rare cases may spurt violently, causing burns. Please be careful.



Beware of sudden bursts

- Wipe off any water droplets from the outside of the product before placing in a microwave.
- Do not heat when empty or with very little inside.
- Consult the instruction manual of your microwave before use.
- The entire product will become hot after heating in a microwave. Use oven gloves to hold the body or handle when carrying. Do not place directly onto items that are not heat resistant such as a vinyl tablecloth. Always place on a pot stand.


Product Care

- ⚠ Use a soft sponge and neutral detergent to clean this product.
- ⚠ Do not use cleansers or sponges that contain abrasives, as doing so may scratch the glass.

- The glass body, lid, and shaft are dishwasher safe. Be sure to read the instruction manual provided with your dishwasher before use.
- If the glass is particularly dirty, use a diluted household bleach. Be sure to read the handling precautions of the household bleach thoroughly. Rinse thoroughly with water after bleaching.

- Please take extra care when cleaning the inner side of the glass. Washing the inner side forcefully with a twisting motion as if wringing a towel can cause breakage and unexpected injury.

Compatible		Incompatible			
					
Sponge	Neutral detergent	Cleanser	Abrasive sponge	Steel scrubbing brush	Nylon abrasive scrubbing brush



About the Motor Handle

Precautions for Use

! Avoid subjecting the motor handle to strong impacts such as from dropping from the table to the floor, as this may cause the product to malfunction.

- Do not disassemble the motor handle. Doing so may cause the product to malfunction.
- The motor handle is not waterproof. Do not allow water to enter the handle or allow the handle to get wet. Doing so may cause the product to malfunction. When cleaning, avoid the motor handle and wash the whisking shaft only.
- When placing the handle set upside down after use, wipe the spring ring thoroughly to remove any residual milk. Failure to do so may allow milk to enter the motor handle and may cause the product to malfunction.
- Do not approach people while the whisking shaft is in motion. There is a risk of hair becoming tangled or other injuries. Handle the product with care.
- Ensure that the whisking shaft is not in motion before changing the batteries.
- Be sure to press the whisking shaft firmly into the motor handle. If the shaft is not pushed in properly, it may come off during use or wobble excessively, preventing proper rotation.
- Do not use the product continuously for one minute or more. Doing so may cause it to malfunction.



Product Care

! The motor handle is not washable.

The motor handle is not waterproof. Washing it with water may cause the product to malfunction. Remove any dirt on the handle by wiping with a dry cloth, or by wiping with a well-wrung cloth then wiping with a dry cloth.

When washing with water after use, remove only the whisking shaft.




● Water-washable

! Not water-washable

The actions shown in the diagram may allow liquid to enter the motor or electrical parts, which may cause the product fail or malfunction.



How to Insert Batteries




Remove the cap by sliding it in the OPEN direction. Insert **two AA alkaline batteries** in the orientation shown in the diagram.

* Batteries are not included with the product.

* Do not mix different types of batteries.

How to Remove the Whisking Shaft



About the Motor

The motor used in this product has a limited lifespan. The motor has reached the end of its lifespan when it no longer functions despite being used correctly according to this instruction manual.

(after approximately 1,500 uses at 30 seconds of continuous operation per use)

Glass made with

HARIO Glass®

MADE IN JAPAN

Sustainable materials

家庭用品品質表示法による表示

品名 耐熱ガラス製器具
使用区分 電子レンジ用
耐熱温度差 120°C

HARIO株式会社

〒103-0006
東京都中央区日本橋富沢町9-3

取扱い上の注意

- 調理の時は外側の水滴をぬぐい、途中で差し水をする時は冷水をさけ、またガラスの部分が熱くなっている時はぬれた布でふれたり、ぬれた所に置かないで下さい。
- 空だきをしないで下さい。
- 洗う時は、研磨材入りたわし、金属たわしやクレンザーなどを使用しないで下さい。
- 使用区分以外には使用しないで下さい。

製品についてのお問い合わせ先

HARIO株式会社

〒103-0006東京都中央区日本橋富沢町9-3
ナビダイヤル:0570-022-555
<https://www.hario.com>

HARIO CO., LTD.

9-3 Nihonbashi Tomizawa-Cho,
Chuo-ku, Tokyo 103-0006 Japan
<https://global.hario.com>

76078600 MLF-35 説明書 2602