

## FAQ

### Grinder

#### [Common]

Q. Should I wash the coffee grinder before I use it?  
What is the best way to maintain this product?

Q. What are the general rules for coffee ground coarseness?

Q. Where do I put the coffee beans into the coffee grinder?  
Where does the ground coffee come out?

#### [Coffee Mill Ceramic Slim\_MSS-1]

Q. How do I assemble the Coffee Mill Ceramic Slim (MSS-1)?



#### [Ceramic Coffee Mill\_MSCS-2]

Q. How do I assemble the Ceramic Coffee Mill (MSCS-1)?



Q. I found a scratch or a crack like mark, on the bottom of glass bowl. Is it defective?

#### [Coffee Mill "Column"\_CM-502C]

Q. How do I assemble the Coffee Mill "Column" (CM-502C)?



#### [Coffee Mill smart G\_MSG-2-T/TB]

Q. How do I assemble the Coffee Mill smart G (MSG-2-T/TB)?



Q. How do I take it apart(MSG-2-T/TB)?

#### [Aluminum Alloy Coffee Mill PRISM\_MSA-2-SV/B]

Q. How do I assemble the Aluminum Alloy Coffee Mill PRISM (MSA-2-B/SV)?



#### [Electric Coffee Grinder\_EVCG-8/EVC-8]

Q. Is it possible to use Japanese electric appliance (100V) in any place outside of Japan?

