

FAQ

Glass Top Tajine

Q. I cannot remove the burned food from the bottom. Please tell me what I should do.

A. Please clean the pot as follows:

1. Soak the burned food in water.



2. Heat it. Stop heating when the water starts to boil.



3. Drain the water in the pot. Rub the burned food with a wet melamine sponge.



4. Repeat 1-3 above until you can remove the burned food.

